



## Construction Notes

1. Join the inlet to the polluted supply taking any suitable step to remove bulky material before it can enter the sump.
2. Connect the outlet to a safe disposal area following the ESCP/SWMP.
3. Place a geotextile liner on the outside of the pit.
4. Install a removable baffle, central to the inflow/outflow and normal to the direction of flow, ensuring that it reaches 500 mm below the invert of the outlet pipe.
5. Install a cover over the pit with an observation port and access cover.