



## Construction Notes

1. Join the inlet to the stormwater, taking any suitable steps to remove bulky or coarse material before it can enter the tank.
2. Connect the outlet to a safe disposal area following the SWMP.
3. Install a removable baffle, central to the inflow/outflow and normal to the direction of flow, ensuring that it reaches 500 mm below the invert of the outlet pipe.
4. Install a cover over the pit with an observation port and access cover.